AMERICAN NATIONAL STANDARD

ANSI/ISA-75.01.01-2002

(IEC 60534-2-1 Mod)

-00ja para

Flow Equations for Sizing Control Valves

NOTICE OF COPYRIGHT

This is a copyrighted document and may not be copied or distributed in any form or manner without the permission of ISA. This copy of the document was made for the sole use of the person to whom ISA provided it and is subject to the restrictions stated in ISA's license to that person. It may not be provided to any other person in print, electronic, or any other form. Violations of ISA's copyright will be prosecuted to the fullest extent of the law and may result in substantial civil and criminal penalties.



ISA–The Instrumentation, Systems, and **Automation Society**

Approved 3 July 2002

ANSI/ISA-75.01.01-2002 (60534 21 Mod) Flow Equations for Sizing Control Valves

ISBN: 1-55617-780-1

Copyright © 2002 by ISA–The Instrumentation, Systems, and Automation Society. All rights reserved. Not for resale. Printed in the United States of America. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), without the prior written permission of the Publisher.

ISA 67 Alexander Drive P. O. Box 12277 Research Triangle Park, North Carolina 27709 USA

Preface

This preface, as well as all footnotes and annexes, is included for information purposes and is not part of ANSI/ISA-75.01.01-2002 (IEC 60534-2-1 Mod).

The standards referenced within this document may contain provisions which, through reference in this text, constitute requirements of this document. At the time of publication, the editions indicated were valid. All standards are subject to revision, and parties to agreements based on this document are encouraged to investigate the possibility of applying the most recent editions of the standards indicated within this document. Members of IEC and ISO maintain registers of currently valid International Standards. ANSI maintains registers of currently valid U.S. National Standards.

This document has been prepared as part of the service of ISA—The Instrumentation, Systems, and Automation Society, toward a goal of uniformity in the field of instrumentation. To be of real value, this document should not be static but should be subject to periodic review. Toward this end, the Society welcomes all comments and criticisms and asks that they be addressed to the Secretary, Standards and Practices Board; ISA; 67 Alexander Drive; P. O. Box 12277; Research Triangle Park, NC 27709; Telephone (919) 549-8411; Fax (919) 549-8288; E-mail: standards@isa.org.

The ISA Standards and Practices Department is aware of the growing need for attention to the metric system of units in general, and the International System of Units (SI) in particular, in the preparation of instrumentation standards. The Department is further aware of the benefits to USA users of ISA standards of incorporating suitable references to the SI (and the metric system) in their business and professional dealings with other countries. Toward this end, this Department will endeavor to introduce SI-acceptable metric units in all new and revised standards, recommended practices, and technical reports to the greatest extent possible. *Standard for Use of the International System of Units (SI): The Modern Metric System*, published by the American Society for Testing & Materials as IEEE/ASTM SI 10-97, and future revisions, will be the reference guide for definitions, symbols, abbreviations, and conversion factors.

It is the policy of ISA to encourage and welcome the participation of all concerned individuals and interests in the development of ISA standards, recommended practices, and technical reports. Participation in the ISA standards-making process by an individual in no way constitutes endorsement by the employer of that individual, of ISA, or of any of the standards, recommended practices, and technical reports that ISA develops.

CAUTION — ISA ADHERES TO THE POLICY OF THE AMERICAN NATIONAL STANDARDS INSTITUTE WITH REGARD TO PATENTS. IF ISA IS INFORMED OF AN EXISTING PATENT THAT IS REQUIRED FOR USE OF THE STANDARD, IT WILL REQUIRE THE OWNER OF THE PATENT TO EITHER GRANT A ROYALTY-FREE LICENSE FOR USE OF THE PATENT BY USERS COMPLYING WITH THE STANDARD OR A LICENSE ON REASONABLE TERMS AND CONDITIONS THAT ARE FREE FROM UNFAIR DISCRIMINATION.

EVEN IF ISA IS UNAWARE OF ANY PATENT COVERING THIS STANDARD, THE USER IS CAUTIONED THAT IMPLEMENTATION OF THE STANDARD MAY REQUIRE USE OF TECHNIQUES, PROCESSES, OR MATERIALS COVERED BY PATENT RIGHTS. ISA TAKES NO POSITION ON THE EXISTENCE OR VALIDITY OF ANY PATENT RIGHTS THAT MAY BE INVOLVED IN IMPLEMENTING THE STANDARD. ISA IS NOT RESPONSIBLE FOR IDENTIFYING ALL PATENTS THAT MAY REQUIRE A LICENSE BEFORE IMPLEMENTATION OF THE STANDARD OR FOR INVESTIGATING THE VALIDITY OR SCOPE OF ANY PATENTS BROUGHT TO ITS ATTENTION. THE USER SHOULD CAREFULLY INVESTIGATE RELEVANT PATENTS BEFORE USING THE STANDARD FOR THE USER'S INTENDED APPLICATION. HOWEVER, ISA ASKS THAT ANYONE REVIEWING THIS STANDARD WHO IS AWARE OF ANY PATENTS THAT MAY IMPACT IMPLEMENTATION OF THE STANDARD NOTIFY THE ISA STANDARDS AND PRACTICES DEPARTMENT OF THE PATENT AND ITS OWNER.

ADDITIONALLY, THE USE OF THIS STANDARD MAY INVOLVE HAZARDOUS MATERIALS, OPERATIONS OR EQUIPMENT. THE STANDARD CANNOT ANTICIPATE ALL POSSIBLE APPLICATIONS OR ADDRESS ALL POSSIBLE SAFETY ISSUES ASSOCIATED WITH USE IN HAZARDOUS CONDITIONS. THE USER OF THIS STANDARD MUST EXERCISE SOUND PROFESSIONAL JUDGMENT CONCERNING ITS USE AND APPLICABILITY UNDER THE USER'S PARTICULAR CIRCUMSTANCES. THE USER MUST ALSO CONSIDER THE APPLICABILITY OF ANY GOVERNMENTAL REGULATORY LIMITATIONS AND ESTABLISHED SAFETY AND HEALTH PRACTICES BEFORE IMPLEMENTING THIS STANDARD.

The following people served as members of ISA Subcommittee SP75.01:

NAME

* One vote per company.

COMPANY

W. Weidman, Managing Director Parsons Energy & Chemicals Group J. George, Chair **Richards Industries** H. B. Services Partners H. Baumann H. Boger* Masoneilan Dresser G. Borden Consultant Metso Automation USA Inc. S. Boyle Consultant Flowserve Corporation C. Crawford A. Glenn M. Hanusa* Fisher Controls International Inc. H. Hoffmann Samson AG **Power Chokes** J. McCaskill Chagrin Valley Controls Inc. A. McCaulev opiapara J. Ozol Northern States Power W. Rahmeyer Utah State University J. Reed Norriseal J. Reid Cashco Inc. M. Riveland* Fisher Controls International Inc. K. Roth Arthur D. Little K. Schoonover Con-Tek Valves Inc. E. Skovgaard Leslie Controls Inc. D. Van Staveren **Bechtel Corporation** F. Volpe* Masoneilan Dresser

The following people served as members of ISA Committee SP75:

NAME

COMPANY

W. Weidman, Managing Director	Parsons Energy & Chemicals Group
A Abromaitic	Red Valve Company Inc.
A. Abiomatics H. Backinger	Consultant
G Barb	Consultant
G. Dalb H. Baumann	H B Services Partners II C
	Emerson Process Management
J. Deall	Curtice Wright Flow Control Corporation
N. Blackwoll	Industrial Valvo
VV. Diackwell H. Rogor*	Masanailan Drassar
G. Bordon	
S. Boulo	Moteo Automation USA Inc
D. Brodin	Fisher Controls International Inc.
	Fisher Controls International, Inc.
	Pravair Inc
A. Liigeis H. Fuller	Valveon Corporation
	Richards Industries
	Bantrel Inc
R leanes	
I Kersh	M W Kellogg Company
C. Langford	Cullen G + angford Inc
W Lestan*	Dresser Valve Division
A Libke	SPX Valves & Controls DeZurik Products
R. Louviere	Services Unlimited
J. McCaskill	Power Chokes
A. McCaulev	Chagrin Valley Controls, Inc.
R. McEver*	Emerson Valve Automation
H. Miller	Control Components, Inc.
T. Molloy	CMES Inc.
L. Ormanoski	Frick Company
J. Ozol	Northern States Power
W. Rahmeyer	Utah State University
J. Reed	Norriseal
K. Schoonover	Con-Tek Valves, Inc.
A. Shea*	SPX Valves & Controls
E. Skovgaard	Leslie Controls, Inc.
H. Sonderegger	Anvil International Inc.

* One vote per company.

This standard was approved for publication by the ISA Standards and Practices Board on 8 April 2002.

NAME

M. Zielinski D. Bishop D. Bouchard M. Cohen M. Coppler B. Dumortier W. Holland E. Icayan A. Iverson R. Jones V. Maggioli T. McAvinew A. McCauley, Jr. G. McFarland R. Reimer J. Rennie H. Sasajima I. Verhappen R. Webb W. Weidman J. Weiss M. Widmeyer C. Williams G. Wood

COMPANY

Emerson Process Management David N Bishop, Consultant Paprican Consultant Ametek. Inc. Schneider Electric Southern Company ACES Inc Ivy Optiks Dow Chemical Company Feltronics Corporation ForeRunner Corporation Chagrin Valley Controls, Inc. Westinghouse Process Control Inc. Rockwell Automation Factory Mutual Research Corporation Yamatake Corporation Syncrude Canada Ltd. **POWER Engineers** Parsons Energy & Chemicals Group **KEMA** Consulting Consultant Eastman Kodak Company Copia para pr Graeme Wood Consulting

Contents

1	Sc	ope	. 11		
2	No	rmative references	. 11		
3	De	finitions	. 11		
4	Ins	stallation	. 12		
5	Sy	mbols	. 13		
6	Siz	zing equations for incompressible fluids	. 14		
6	5.1	Turbulent flow	. 14		
6	.2	Non-turbulent (laminar and transitional) flow	. 15		
7	Siz	zing equations for compressible fluids	. 16		
7	.1	Turbulent flow	. 16		
7	.2	Non-turbulent (laminar and transitional) flow	. 18		
8	De	termination of correction factors	. 19		
8	.1	Piping geometry factor F_{P}	. 19		
8	.2	Reynolds number factor <i>F</i> _R	. 20		
8	.3	Liquid pressure recovery factors \mathcal{F}_{L} or \mathcal{F}_{LP}	. 21		
8	.4	Liquid critical pressure ratio factor $F_{\rm F}$. 21		
8	.5	Expansion factor	. 22		
8	.6	Pressure differential ratio factor x_{T} or x_{TP}	. 22		
8	.7	Specific heat ratio factor F_{γ}	. 23		
8	.8	Compressibility factor Z	. 23		
Anr	nex .	A (informative) — Derivation of valve style modifier F_{d}	. 35		
Anr	nex	B (informative) — Control valve sizing flow charts	. 41		
Anr	nex	C (informative) — Physical constants ¹⁾	. 45		
Anr	Annex D (informative) — Alternate non-turbulent flow calculation method				
Anr	nex	E (informative) — Units conversions	. 51		

Annex F (informative) — Examples of sizing calculations	55
Annex G (informative) — Equations for Reynolds number factor, F_{R}	71
Annex H (informative) — Bibliography	73

copia para perfeccionamiento

FOREWORD

NOTE This foreword is included for information purposes only and is identical to the foreword found in IEC 60534-2-1.

1) The IEC (International Electrotechnical Commission) is a worldwide organization for standardization comprising all national electrotechnical committees (IEC National Committees). The object of the IEC is to promote international co-operation on all questions concerning standardization in the electrical and electronic fields. To this end and in addition to other activities, the IEC publishes International Standards. Their preparation is entrusted to technical committees; any IEC National Committee interested in the subject dealt with may participate in this preparatory work. International, governmental and non-governmental organizations liaising with the IEC also participate in this preparation. The IEC collaborates closely with the International Organization for Standardization (ISO) in accordance with conditions determined by agreement between the two organizations.

2) The formal decisions or agreements of the IEC on technical matters express, as nearly as possible, an international consensus of opinion on the relevant subjects since each technical committee has representation from all interested National Committees.

3) The documents produced have the form of recommendations for international use and are published in the form of standards, technical reports or guides and they are accepted by the National Committees in that sense.

4) In order to promote international unification, IEC National Committees undertake to apply IEC International Standards transparently to the maximum extent possible in their national and regional standards. Any divergence between the IEC Standard and the corresponding national or regional standard shall be clearly indicated in the latter.

5) The IEC provides no marking procedure to inclicate its approval and cannot be rendered responsible for any equipment declared to be in conforming with one of its standards.

6) Attention is drawn to the possibility that some of the elements of this International Standard may be the subject of patent rights. The IEC shall not be held responsible for identifying any or all such patent rights.

International Standard IEC 60534-2-1 has been prepared by subcommittee 65B: Devices, of IEC technical committee 65: Industrial-process measurement and control.

The text of this standard is based on the following documents:

FDIS	Report on voting
65B/347/FDIS	65B/357/RVD

Full information on the voting for the approval of this standard can be found in the report on voting indicated in the above table.

The current edition of IEC 60534-2-1 cancels and replaces the first edition of both IEC 60534-2 published in 1978, and IEC 60534-2-2 published in 1980, which cover incompressible and compressible fluid flow, respectively.

IEC 60534-2-1 covers sizing equations for both incompressible and compressible fluid flow.

ANSI/ISA-75.01.01-2002 (IEC 60534-2-1 Mod) - 10 -

Annexes A, B, C, D F, G, and H are for information only.

A bilingual version of this standard may be issued at a later date.

copia para perfeccionamiento

1 Scope

ANSI/ISA-75.01.01-2002 includes equations for predicting the flow coefficient of compressible and incompressible fluids through control valves.

The equations for incompressible flow are based on standard hydrodynamic equations for Newtonian incompressible fluids. They are not intended for use when non-Newtonian fluids, fluid mixtures, slurries, or liquid-solid conveyance systems are encountered.

At very low ratios of pressure differential to absolute inlet pressure ($\Delta P/P_1$), compressible fluids behave similarly to incompressible fluids. Under such conditions, the sizing equations for compressible flow can be traced to the standard hydrodynamic equations for Newtonian incompressible fluids. However, increasing values of $\Delta P/P_1$ result in compressibility effects that require that the basic equations be modified by appropriate correction factors. The equations for compressible fluids are for use with gas or vapor and are not intended for use with multiphase streams such as gas-liquid, vapor-liquid or gas-solid mixtures.

For compressible fluid applications, this part of ANSI/ISA-75.01.01-2002 is valid for all valves. However, manufacturers of some valves with $x_T \ge 0.84$ have reported minor inaccuracies (see Annex H). Caution must also be exercised when applying the equations for compressible fluids to gaseous mixtures of compounds, particularly near phase boundaries.

The accuracy of results computed with the equations in this standard will be governed by the accuracy of the constituent coefficients and the process data supplied. Methods of evaluating the coefficients used in the equations presented herein are given in ANSI/ISA-75.02 1996. The stated accuracy associated with the coefficients in that document is $\pm 5\%$ when $C_v/d^2 < 0.047 N_{18}$. Reasonable accuracy can only be maintained for control valves if $C_v/d^2 < 0.047 N_{18}$.

2 Normative references

The following normative documents contain provisions which, through reference in this text, constitute provisions of this part of ANSI/ISA-75.01.01-2002. At the time of publication, the editions indicated were valid. All normative documents are subject to revision, and parties to agreements based on this part of ANSI/ISA-75.01.01-2002 are encouraged to investigate the possibility of applying the most recent editions of the normative documents indicated below. Members of IEC and ISO maintain registers of currently valid International Standards.

IEC 60534-1:1987, Industrial-process control valves – Part 1: Control valve terminology and general considerations

IEC 60534-2-3:1997, Industrial-process control valves – Part 2: Flow capacity – Section 3: Test procedures

ANSI/ISA-75.02-1996, Control Valve Capacity Test Procedures

ANSI/ISA-75.05.01-2001, Control Valve Terminology

3 Definitions

For the purpose of ANSI/ISA-75.01.01-2002, definitions given in IEC 60534-2-1 apply with the addition of the following:

3.1 valve style modifier F_{d}

the ratio of the hydraulic diameter of a single flow passage to the diameter of a circular orifice, the area of which is equivalent to the sum of areas of all identical flow passages at a given travel. It should be stated by the manufacturer as a function of travel (see Annex A).

4 Installation

In many industrial applications, reducers or other fittings are attached to the control valves. The effect of these types of fittings on the nominal flow coefficient of the control valve can be significant. A correction factor is introduced to account for this effect. Additional factors are introduced to take account of the fluid property characteristics that influence the flow capacity of a control valve.

In sizing control valves, using the relationships presented herein, the flow coefficients calculated are assumed to include all head losses between points A and B, as shown in Figure 1.



5 Symbols

Symbol	Description	Unit
С	Flow coefficient (K_v , C_v)	Various (see IEC 60534-1) (see note
		4)
C.	Assumed flow coefficient for iterative purposes	Various (see IEC 60534-1) (see note
-1		4)
d	Nominal valve size	mm (in)
D	Internal diameter of the piping	mm (in)
D_1	Internal diameter of upstream piping	mm (in)
D_2	Internal diameter of downstream piping	mm (in)
	Orifice diameter	mm (in)
F,	Valve style modifier (see Annex A)	Dimensionless (see note 4)
E_	Liquid critical pressure ratio factor	Dimensionless
F,	Liquid pressure recovery factor of a control valve without attached fittings	Dimensionless (see note 4)
E D	Combined liquid pressure recovery factor and piping geometry factor of a control	Dimensionless (see note 4)
, Th	valve with attached fittings	, , , , , , , , , , , , , , , , , , ,
F _P	Piping geometry factor	Dimensionless
F _R	Reynolds number factor	Dimensionless
F_{γ}	Specific heat ratio factor	Dimensionless
G _g	Gas specific gravity (ratio of density of flowing gas to density of air with both at standard conditions, which is considered in this practice to be equal to the ratio of	Dimensionless
	the molecular weight of gas to molecular weight of air	
М	Numerical exerctants (see Table 1)	kg/kg-mol (lb/lb-mol)
N	Inter constants (see Table T)	Various (see note 1)
P ₁	nier absolute static pressure measured at point A (see Future 1)	kPa or bar (psia)(see note 2)
P ₂	Outlet absolute static pressure measured at point B (see Figure 1)	kPa or bar (psia)
P _c	Absolute thermodynamic critical pressure	kPa or bar (psia)
P _r	Reduced pressure (P_1/P_c)	Dimensionless
Pv	Absolute vapor pressure of the liquid at nict temperature	kPa or bar (psia)
ΔP	Differential pressure between upstream and downstream pressure taps $(P_1 - P_2)$	kPa or bar (psi)
Q	Volumetric flow rate (see note 5)	m³/h (gpm, scfh)
Re_v	Valve Reynolds number	Dimensionless
<i>T</i> ₁	Inlet absolute temperature	K (R)
T_{c}	Absolute thermodynamic critical temperature	K (R)
T,	Reduced temperature (T_1/T_c)	Dimensionless
ts	Absolute reference temperature for standard cubic meter	K (R)
Ŵ	Mass flow rate	kg/h (lbs/h)
x	Ratio of pressure differential to inlet absolute pressure $(\Delta P/P_1)$	Dimensionless
x _T	Pressure differential ratio factor of a control valve without attached fittings at	Dimensionless (see note 4)
x _{TP}	Pressure differential ratio factor of a control valve with attached fittings at choked flow	Dimensionless (see note 4)
Y	Expansion factor	Dimensionless
Ζ	Compressibility factor	Dimensionless
v	Kinematic viscosity	m^2/s (cS) (see note 3)
ρ_1	Density of fluid at P_1 and T_1	kg/m ³ (lb/ft ³)
ρ_1/ρ_0	Relative density ($\rho_1/\rho_0 = 1.0$ for water at 15°C)	Dimensionless
γ	Specific heat ratio	Dimensionless
ζ	Velocity head loss coefficient of a reducer, expander or other fitting attached to a control valve or valve trim	Dimensionless

51	Upstream velocity head loss coefficient of fitting	Dimensionless						
52	Downstream velocity head loss coefficient of fitting Dimensionless							
ζ _{Ρ1}	Linlet Bernoulli coefficient Dimensionless							
S B2	ζ_{B2} Outlet Bernoulli coefficient Dimensionless							
NOTE 1 To	determine the units for the numerical constants, dimensional analysis may be perform	ed on the appropriate equations using						
the units giver	n in Table 1.							
NOTE 2 1 bar = 10^2 kPa = 10^5 Pa								
NOTE 3 1 centistoke = 10^{-6} m ² /s								
NOTE 4 These values are travel-related and should be stated by the manufacturer.								
NOTE 5 Volumetric flow rates in cubic meters per hour, identified by the symbol Q, refer to standard conditions. The standard cubic								
meter is taken at 1013.25 mbar and either 273 K or 288 K (see Table 1).								

6 Sizing equations for incompressible fluids

The equations listed below identify the relationships between flow rates, flow coefficients, related installation factors, and pertinent service conditions for control valves handling incompressible fluids. Flow coefficients may be calculated using the appropriate equation selected from the ones given below. A sizing flow chart for incompressible fluids is given in Annex B.

6.1 Turbulent flow

The equations for the flow rate of a Newtonian liquid through a control valve when operating under non-choked flow conditions are derived from the basic formula as given in IEC 60534-2-1.

6.1.1 Non-choked turbulent flow

6.1.1.1 Non-choked turbulent flow without attached fittings

$$\left[Applicable if \Delta P < F_{L}^{2} (P_{1} - F_{F} P_{v}) \right]$$

The flow coefficient shall be determined by

Eq. 1 $C = \frac{Q}{N_1} \sqrt{\frac{\rho_1 / \rho_o}{\Delta P}}$

NOTE 1 The numerical constant N_1 depends on the units used in the general sizing equation and the type of flow coefficient: K_v or C_v .

NOTE 2 An example of sizing a valve with non-choked turbulent flow without attached fittings is given in Annex F.

6.1.1.2 Non-choked turbulent flow with attached fittings

$$\left\{ \text{Applicable if } \Delta P < \left[\left(F_{LP} \ / \ F_{p} \right)^{2} \left(P_{1} - F_{F} P_{v} \right) \right] \right\}$$

The flow coefficient shall be determined as follows:

Eq. 2
$$C = \frac{Q}{N_1 F_p} \sqrt{\frac{\rho_1 / \rho_o}{\Delta P}}$$

NOTE Refer to 8.1 for the piping geometry factor $F_{\rm P}$.

6.1.2 Choked turbulent flow

The maximum rate at which flow will pass through a control valve at choked flow conditions shall be calculated from the following equations:

6.1.2.1 Choked turbulent flow without attached fittings

Applicable if $\Delta P \geq F_1^2 (P_1 - F_F P_y)$

The flow coefficient shall be determined as follows:

Eq. 3
$$C = \frac{Q}{N_1 F_L} \sqrt{\frac{\rho_1 / \rho_o}{P_1 - F_F P_v}}$$

NOTE An example of sizing a valve with choked flow without attached fittings is given in Annex F. amier

6.1.2.2 Choked turbulent flow with attached fittings

$$\left[Applicable \text{ if } \Delta P \geq \left(F_{LP} / F_{p} \right)^{2} \left(P_{1} - F_{F} P_{v} \right) \right]$$

The following equation shall be used to calculate the flow coefficient:

6.2 Non-turbulent (laminar and transitional) flow

 $C = \frac{Q}{N_1 F_{LP}} \sqrt{\frac{\rho_1 / \rho_o}{P_1 - F_F P_v}}$

The equations for the flow rate of a Newtonian liquid through a control valve when operating under nonturbulent flow conditions are derived from the basic formula as given in IEC 60534-2-1. This equation is applicable if $Re_v < 10,000$ (see Equation 28).

6.2.1 Non-turbulent flow without attached fittings

The flow coefficient shall be calculated as follows:

Eq. 5
$$C = \frac{Q}{N_1 F_R} \sqrt{\frac{\rho_1 / \rho_o}{\Delta P}}$$

6.2.2 Non-turbulent flow with attached fittings

For non-turbulent flow, the effect of close-coupled reducers or other flow disturbing fittings is unknown. While there is no information on the laminar or transitional flow behavior of control valves installed between pipe reducers, the user of such valves is advised to utilize the appropriate equations for line-sized valves in the calculation of the $F_{\rm R}$ factor. This should result in conservative flow coefficients since additional turbulence created by reducers and expanders will further delay the onset of laminar flow. Therefore, it will tend to increase the respective F_{R} factor for a given valve Reynolds number.

7 Sizing equations for compressible fluids

The equations listed below identify the relationships between flow rates, flow coefficients, related installation factors, and pertinent service conditions for control valves handling compressible fluids. Flow rates for compressible fluids may be encountered in either mass or volume units and thus equations are necessary to handle both situations. Flow coefficients may be calculated using the appropriate equations selected from the following. A sizing flow chart for compressible fluids is given in Annex B.

The flow rate of a compressible fluid varies as a function of the ratio of the pressure differential to the absolute inlet pressure $(\Delta P/P_1)$, designated by the symbol x. At values of x near zero, the equations in this section can be traced to the basic Bernoulli equation for Newtonian incompressible fluids. However, increasing values of x result in expansion and compressibility effects that require the use of appropriate factors (see Buresh, Schuder, and Driskell references).

7.1 Turbulent flow

7.1.1 Non-choked turbulent flow

The flow coefficient shall be calculated using one of the following equations: Eq. 6 $C = \frac{W}{N_6 Y \sqrt{x P_1 \rho_1}}$ para perfecci

Eq. 7

Eq. 8a

Eq. 7
$$C = \frac{W}{N_8 P_1 Y} \sqrt{\frac{T_1 Z}{xM}}$$

Eq. 8a
$$C = \frac{Q}{N_9 P_1 Y} \sqrt{\frac{MT_1 Z}{xM}}$$

Eq. 8b
$$C = \frac{Q}{N_7 P_1 Y} \sqrt{\frac{GgT_1 Z}{x}}$$

NOTE 1 Refer to 8.5 for details of the expansion factor Y.

NOTE 2 See Annex C for values of M.

7.1.1.2 Non-choked turbulent flow with attached fittings

Applicable if $x < F_{y} x_{TP}$

The flow coefficient shall be determined from one of the following equations:

Eq. 9
$$C = \frac{W}{N_6 F_p Y \sqrt{x P_1 \rho_1}}$$

Eq. 10 $C = \frac{W}{N_8 F_p P_1 Y} \sqrt{\frac{T_1 Z}{xM}}$

Eq. 11a
$$C = \frac{Q}{N_{9}F_{p}P_{1}Y}\sqrt{\frac{MT_{1}Z}{x}}$$

Eq. 11b
$$C = \frac{Q}{N_7 F_p P_1 Y} \sqrt{\frac{GgT_1 Z}{x}}$$

NOTE 1 Refer to 8.1 for the piping geometry factor $F_{\rm P}$.

NOTE 2 An example of sizing a valve with non-choked turbulent flow with attached fittings is given in Annex F.

7.1.2 Choked turbulent flow

The maximum rate at which flow will pass through a control value at choked flow conditions shall be calculated as follows:

7.1.2.1 Choked turbulent flow without attached fittings

$$\left[Applicable if x \geq F_{\gamma} x_{T} \right]$$

The flow coefficient shall be calculated from one of the following equations:

Eq. 12

$$C = \frac{VV}{0.667N_6} \int F_{\gamma} \times_{\mathrm{T}} P_1 \rho_1$$

Eq. 13
$$C = \frac{W}{0.667N_8P_1} \sqrt{\frac{I_1Z}{F_{\gamma}x_{T}M}}$$

Eq. 14a
$$C = \frac{Q}{0.667N_9P_1}\sqrt{\frac{MT_1Z}{F_{\gamma}x_{\tau}}}$$

Eq. 14b
$$C = \frac{Q}{0.667N_7P_1}\sqrt{\frac{GgT_1Z}{F_{\gamma}x_{\tau}}}$$

7.1.2.2 Choked turbulent flow with attached fittings

Applicable if
$$x \ge F_{\gamma} x_{TP}$$

The flow coefficient shall be determined using one of the following equations:

Eq. 15
$$C = \frac{W}{0.667N_{6}F_{p}\sqrt{F_{\gamma}x_{TP}P_{1}\rho_{1}}}$$

Eq. 16
$$C = \frac{W}{0.667N_8F_pP_1}\sqrt{\frac{T_12}{F_\gamma x_{TI}}}$$

Eq. 17a
$$C = \frac{Q}{0.667N_9F_pP_1}\sqrt{\frac{MT_1Z}{F_\gamma x_{TP}}}$$

Eq. 17b
$$C = \frac{Q}{0.667N_7F_pP_1}\sqrt{\frac{GgT_1Z}{F_\gamma x_{TP}}}$$

7.2 Non-turbulent (laminar and transitional) flow

The equations for the flow rate of a Newtonian fluid through a control valve when operating under non-turbulent flow conditions are derived from the basic formula as given in IEC 60534-2-1. These equations are applicable if $Re_v < 10,000$ (see Equation 28). In this subclause, density correction of the gas is given by $(P_1 + P_2) / 2$ due to non-isentropic expansion.

7.2.1 Non-turbulent flow without attached fittings

The flow coefficient shall be calculated from one of the following equations:

Eq. 18

$$C = \frac{W}{N_{27}F_{\rm R}} \sqrt{\frac{T_1}{\Delta P \left(P_1 + P_2\right)M}}$$

NOTE An example of sizing a valve with small flow trim is given in Annex D.

 $- N_{22}\overline{F_{\mathsf{R}}} \sqrt{\Delta P(P_1 + P_2)}$

7.2.2 Non-turbulent flow with attached fittings

For non-turbulent flow, the effect of close-coupled reducers or other flow-disturbing fittings is unknown. While there is no information on the laminar or transitional flow behavior of control valves installed between pipe reducers, the user of such valves is advised to utilize the appropriate equations for line-sized valves in the calculation of the $F_{\rm R}$ factor. This should result in conservative flow coefficients since additional turbulence created by reducers and expanders will further delay the onset of laminar flow. Therefore, it will tend to increase the respective $F_{\rm R}$ factor for a given valve Reynolds number.

8 Determination of correction factors

8.1 Piping geometry factor $F_{\rm P}$

The piping geometry factor F_p is necessary to account for fittings attached upstream and/or downstream to a control valve body. The F_p factor is the ratio of the flow rate through a control valve installed with attached fittings to the flow rate that would result if the control valve was installed without attached fittings and tested under identical conditions which will not produce choked flow in either installation (see Figure 1). To meet the accuracy of the F_p factor of ±5%, the F_p factor shall be determined by test in accordance with ANSI/ISA-75.02-1996.

When estimated values are permissible, the following equation shall be used:

Eq. 20
$$F_{p} = \frac{1}{\sqrt{1 + \frac{\Sigma\zeta}{N_{2}} \left(\frac{C_{i}}{d^{2}}\right)^{2}}}$$

In this equation, the factor $\Sigma \zeta$ is the algebraic sum of all of the effective velocity head loss coefficients of all fittings attached to the control valve. The velocity head loss coefficient of the control valve itself is not included.

Eq. 21
$$\Sigma \zeta = \zeta_1 + \zeta_2 + \zeta_{B1} - \zeta_{B2}$$

In cases where the piping diameters approaching and leaving the control value are different, the $\zeta_{\rm B}$ coefficients are calculated as follows:

Eq. 22
$$\zeta_{\rm B} = 1 - \left(\frac{d}{D}\right)^4$$

If the inlet and outlet fittings are short-length, commercially available, concentric reducers, the ζ_1 and ζ_2 coefficients may be approximated as follows:

Eq. 23 Inlet reducer:
$$\zeta_1 = 0.5 \left[1 - \left(\frac{d}{D_1} \right)^2 \right]^2$$

Eq. 24 Outlet reducer (expander):
$$\zeta_2 = 1.0 \left[1 - \left(\frac{d}{D_2} \right)^2 \right]^2$$

Eq. 25 Inlet and outlet reducers of equal size: ζ_1 +

$$\zeta_1 + \zeta_2 = 1.5 \left[1 - \left(\frac{d}{D}\right)^2 \right]^2$$

The $F_{\rm P}$ values calculated with the above ζ factors generally lead to the selection of valve capacities slightly larger than required. This calculation requires iteration. Proceed by calculating the flow coefficient *C* for non-choked turbulent flow.

NOTE Choked flow equations and equations involving F_{P} are not applicable.

Next, establish C_i as follows:

Eq. 26
$$C_i = 1.3C$$

Using C_i from Equation 26, determine F_P from Equation 20. If both ends of the valve are the same size, F_P may instead be determined from Figure 2. Then, determine if

Eq. 27
$$\frac{C}{F_{\rm p}} \leq C_{\rm i}$$

If the condition of Equation 27 is satisfied, then use the C_i established from Equation 26. If the condition of Equation 27 is not met, then repeat the above procedure by again increasing C_i by 30%. This may require several iterations until the condition required in Equation 27 is met. An iteration method more suitable for computers can be found in Annex B.

For graphical approximations of $F_{\rm P}$, refer to Figures 2a and 2b.

8.2 Reynolds number factor F_{R}

The Reynolds number factor F_{R} is required when non-turbulent flow conditions are established through a control valve because of a low pressure differential, a high viscosity, a very small flow coefficient, or a combination thereof.

The F_{R} factor is determined by dividing the flow rate when non-turbulent flow conditions exist by the flow rate measured in the same installation under turbulent conditions.

Tests show that F_{R} can be determined from the curves given in Figure 3a or 3b using a valve Reynolds number calculated from the following equation.

Eq. 28
$$Re_v = \frac{N_4 F_d Q}{v \sqrt{C_i F_L}} \left(\frac{F_L^2 C_i^2}{N_2 D^4} + 1 \right)^{1/4}$$

This calculation will require iteration. Proceed by calculating the flow coefficient *C* for turbulent flow. The valve style modifier F_d converts the geometry of the orifice(s) to an equivalent circular single flow passage. See Table 2 for typical values and Annex A for details. To meet a deviation of ±5% for F_d , the F_d factor shall be determined by test in accordance with IEC 60534-2-3.

NOTE Equations involving F_{P} are not applicable.

Next, establish C_i as per Equation 26.

Apply C_{i} as per Equation 26 and determine F_{R} . F_{R} is determined from Figure 3a for full-size trim valves.

 $F_{\rm R}$ is determined from Figure 3b for reduced trim valves where $C_{\rm i}/d^2$ at rated travel is less then 0.016 $N_{\rm 18}$.

Eq. 29
$$\frac{C}{F_{\rm R}} \leq C_{\rm i}$$

If the condition of Equation 29 is satisfied, then use the C_i established from Equation 26. If the condition of Equation 29 is not met, then repeat the above equation by again increasing C_i by 30 percent. This may require several iterations until the conditions required in Equation 29 are met.

The equations defining nonturbulent flow for full size and reduced trim valves are stated in Annex G.

8.3 Liquid pressure recovery factors $F_{\rm L}$ or $F_{\rm LP}$

8.3.1 Liquid pressure recovery factor without attached fittings F_{1}

 $F_{\rm L}$ is the liquid pressure recovery factor of the valve without attached fittings. This factor accounts for the influence of the valve internal geometry on the valve capacity at choked flow. It is defined as the ratio of the actual maximum flow rate under choked flow conditions to a theoretical, non-choked flow rate which would be calculated if the pressure differential used was the difference between the valve inlet pressure and the apparent *vena contracta* pressure at choked flow conditions. The factor $F_{\rm L}$ may be determined from tests in accordance with ANSI/ISA-75.02-1996. Typical values of $F_{\rm L}$ versus percent of rated flow coefficient are shown in Figure 4.

8.3.2 Combined liquid pressure recovery factor and piping geometry factor with attached fittings F_{LP}

 F_{LP} is the combined liquid pressure recovery factor and piping geometry factor for a control valve with attached fittings. It is obtained in the same manner as F_{L} .

To meet a deviation of $\pm 5\%$ for F_{LP} , F_{LP} shall be determined by testing. When estimated values are permissible, the following equation shall be used:

Eq. 30

$$F_{\rm LP} = \frac{F_{\rm L}}{\sqrt{1 + \frac{F_{\rm L}^2}{N_2} (\Sigma \zeta_1) \left(\frac{C}{d^2}\right)^2}}$$

Here $\Sigma \zeta_1$ is the velocity head loss coefficient, $\zeta_1 + \zeta_{B1}$, of the fitting attached upstream of the valve as measured between the upstream pressure tap and the control valve body inlet.

8.4 Liquid critical pressure ratio factor $F_{\rm F}$

 $F_{\rm F}$ is the liquid critical pressure ratio factor. This factor is the ratio of the apparent *vena contracta* pressure at choked flow conditions to the vapor pressure of the liquid at inlet temperature. At vapor pressures near zero, this factor is 0.96.

Values of $F_{\rm F}$ may be determined from the curve in Figure 5 or approximated from the following equation:

Eq. 31
$$F_{\rm F} = 0.96 - 0.28 \sqrt{\frac{P_{\rm v}}{P_{\rm c}}}$$

8.5 Expansion factor *Y*

The expansion factor *Y* accounts for the change in density as the fluid passes from the valve inlet to the *vena contracta* (the location just downstream of the orifice where the jet stream area is a minimum). It also accounts for the change in the *vena contracta* area as the pressure differential is varied.

Theoretically, Y is affected by all of the following:

- a) ratio of port area to body inlet area;
- b) shape of the flow path;
- c) pressure differential ratio x;
- d) Reynolds number; and
- e) specific heat ratio γ .

The influence of items a), b), c), and e) is accounted for by the pressure differential ratio factor x_{T} , which may be established by air test and which is discussed in 8.6.1.

The Reynolds number is the ratio of inertial to viscous forces at the control valve orifice. In the case of compressible flow, its value is generally beyond the range of influence, except where the flow rate or the C_v is very low or a combination of both exist (see 7.2 and 8.2).

The pressure differential ratio $x_{\rm T}$ is influenced by the specific heat ratio of the fluid.

Y may be calculated using Equation 32.

Eq. 32

The value of *x* for calculation purposes shall not exceed $F_{\gamma} x_{T}$. If $x > F_{\gamma} x_{T}$, then the flow becomes choked and Y = 0.667. See 8.6 and 8.7 ion information on *x*, x_{T} and F_{γ} .

8.6 Pressure differential ratio factor x_{T} or x_{TP}

 $Y = 1 - \frac{x}{3F_{\gamma}x_{\tau}}$

8.6.1 Pressure differential ratio factor without fittings x_{T}

 x_{T} is the pressure differential ratio factor of a control valve installed without reducers or other fittings. If the inlet pressure P_1 is held constant and the outlet pressure P_2 is progressively lowered, the mass flow rate through a valve will increase to a maximum limit, a condition referred to as choked flow. Further reductions in P_2 will produce no further increase in flow rate.

This limit is reached when the pressure differential *x* reaches a value of $F_{\gamma} x_{T}$. The limiting value of *x* is defined as the critical differential pressure ratio. The value of *x* used in any of the sizing equations and in the relationship for *Y* (Equation 32) shall be held to this limit even though the actual pressure differential ratio is greater. Thus, the numerical value of *Y* may range from 0.667, when $x = F_{\gamma} x_{T}$, to 1.0 for very low differential pressures.

The values of x_{τ} may be established by air test. The test procedure for this determination is covered in ANSI/ISA-75.02-1996.

NOTE Representative values of x_T for several types of control valves with full size trim and at full rated openings are given in Table 2. Caution should be exercised in the use of this information. When precise values are required, they should be obtained by test.

8.6.2 Pressure differential ratio factor with attached fittings x_{TP}

If a control value is installed with attached fittings, the value of x_{τ} will be affected.

To meet a deviation of $\pm 5\%$ for x_{TP} , the valve and attached fittings shall be tested as a unit. When estimated values are permissible, the following equation shall be used:

Eq. 33

$$x_{\text{TP}} = \frac{\frac{X_{\text{T}}}{F_{\text{p}}^{2}}}{1 + \frac{X_{\text{T}}\zeta_{\text{i}}}{N_{5}} \left(\frac{C_{\text{i}}}{d^{2}}\right)^{2}}$$

NOTE Values for N_5 are given in Table 1.

In the above relationship, x_{T} is the pressure differential ratio factor for a control valve installed without reducers or other fittings. ζ_{i} is the sum of the inlet velocity head loss coefficients ($\zeta_{1} + \zeta_{B1}$) of the reducer or other fitting attached to the inlet face of the valve.

If the inlet fitting is a short-length, commercially available reducer, the value of ζ may be estimated using Equation 23.

8.7 Specific heat ratio factor F_{γ}

The factor x_{T} is based on air near atmospheric pressure as the flowing fluid with a specific heat ratio of 1.40. If the specific heat ratio for the flowing fluid is not 1.40, the factor F_{γ} is used to adjust x_{T} . Use the following equation to calculate the specific heat ratio factor:

Eq. 34 $F_{\gamma} = \frac{\gamma}{1.40}$

NOTE See Annex C for values of γ and $F\gamma$.

8.8 Compressibility factor Z

Several of the sizing equations do not contain a term for the actual density of the fluid at upstream conditions. Instead, the density is inferred from the inlet pressure and temperature based on the laws of ideal gases. Under some conditions, real gas behavior can deviate markedly from the ideal. In these cases, the compressibility factor *Z* shall be introduced to compensate for the discrepancy. *Z* is a function of both the reduced pressure and reduced temperature (see appropriate reference books to determine *Z*). Reduced pressure *P*_r is defined as the ratio of the actual inlet absolute pressure to the absolute thermodynamic critical pressure for the fluid in question. The reduced temperature *T*_r is defined similarly. That is

Eq. 35
$$P_{\rm r} = \frac{P_1}{P_{\rm c}}$$

Eq. 36 $T_{\rm r} = \frac{T_{\rm 1}}{T_{\rm c}}$

NOTE See Annex C for values of P_c and T_c .

copia para perfeccionamiento

$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		Flow co	efficient C				Formulae ι	ınit		
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	Constant	K,	<i>C</i> ,	W	Q	<i>P</i> , ∆ <i>P</i>	ρ	т	d, D	v
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N,	1 × 10 ⁻¹	8.65 × 10−2	-	m³/h	kPa	kg/m ³	-	-	_
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	I	1	8.65 × 10 ⁻¹	-	m³/h	bar	kg/m ³	-	-	-
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $			1	-	gpm	psia	lbm/ft ³	-	-	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	N ₂	1.60 × 10 ⁻³	$2.14 imes 10^{-3}$	-	-	-	-	-	mm	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			$8.90 imes10^2$	-	-	-	-	-	in	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	N ₄	7.07 × 10 ⁻²	7.60 × 10 ⁻²	-	m³/h	-	-	-	-	m²/s
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$			$8.73 imes10^4$	-	gpm	-	-	-	-	cS
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			2.153×10^4	_	scfh	-	-	-	-	cS
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	N ₅	1.80 × 10 ^{−3}	$2.41 imes 10^{-3}$	-	-	-	-	-	mm	-
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$			$1.00 imes 10^3$	-	-	-	-	-	in	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	N ₆	3.16	2.73	kg/h	_	kPa	kg/m ³	-	-	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		$3.16 imes10^1$	$2.73 imes10^{1}$	kg/h	-	bar	kg/m ³	-	-	-
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$			$6.33 imes10^1$	lbm/h	_	psia	lbm/ft ³	D	-	_
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₇	4.82	4.17	-	m³/h	kPa		-	-	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		4.82 x 10 ²	$4.17 imes10^2$	-	m³/h	bar		-	-	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			1.36 × 10 ³	-	scfh	psia	<u> </u>	_	-	_
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₈	1.10	$9.48 imes10^{-1}$	kg/h	-	kPa 🗸	-	К	-	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		$1.10 imes 10^2$	$9.48 imes 10^1$	kg/h		bar	-	K	-	-
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$			$1.93 imes 10^1$	lbm/h	- (psia	-	R	-	-
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₉	$2.46 imes10^1$	$2.12 imes 10^1$	-	m³/h	kPa	-	К	-	-
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	$(t_s = 0^{\circ}C)$	$2.46 imes10^3$	$2.12 imes 10^3$		<u></u>	bar	-	К	-	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			$6.94 imes10^3$	- 0	scfh	psia	-	R	-	-
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₉	$2.60 imes10^1$	$2.25 imes 10^1$	-0	m³/h	kPa	-	К	-	-
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$(t_{\rm s} = 15^{\circ}{\rm C})$	$2.60 imes10^3$	$2.25 imes 10^3$	· 02	m³/h	bar	-	К	-	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			7.32×10^{3}		scfh	psia	_	R	-	_
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₁₈	$8.65 imes 10^{-1}$	1.00	-	-	-	-	-	mm	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			6.45×10^2	-	-	-	-	-	in	-
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₁₉	2.5	23	-	-	-	-	-	mm	-
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$			9.06 × 10 ⁻²	-	-	-	-	-	in	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	N ₂₂	1.73×10^{1}	1.50×10^{1}	-	m³/h	kPa	-	K	-	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	$(t_s = 0^{\circ}C)$	1.73×10^{3}	1.50 × 10 ³	-	m³/h	bar	-	K	-	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			4.92×10^{3}	-	scfh	psia	-	R	-	-
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	N ₂₂	$1.84 imes 10^{1}$	$1.59 imes 10^{1}$	-	m³/h	kPa	-	К	-	-
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	$(t_{s} = 15^{\circ}C)$	$1.84 imes 10^{3}$	$1.59 imes 10^{3}$	-	m³/h	bar	-	K	-	-
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$			5.20 × 10 ³	-	scfh	psia	-	R	-	-
$(t_{\rm s}=0^{\circ}{\rm C})$ 7.75×10 ⁻¹ 6.70×10 ⁻¹ kg/h – bar – K – –	N ₂₇	7.75 × 10 ⁻¹	6.70 × 10 ⁻¹	kg/h	-	kPa	-	К	-	-
	$(t_s = 0^{\circ}C)$	7.75 × 10 ⁻¹	6.70 × 10 ⁻¹	kg/h	-	bar	-	K	-	-
1.37 × 10 ¹ lbm/h – psia – R – –		ļ	1.37×10^{1}	lbm/h	_	psia		R	-	_
N_{32} 1.40 x 10 ² 1.27 × 10 ² mm -	N ₃₂	1.40 x 10 ²	$1.27 imes 10^2$	-	-	-	-	-	mm	-
1.70 – – – – – in –			1.70	-	-	-	-	-	in	-

Table 1 — Numerical constants N

NOTE Use of the numerical constants provided in this table together with the practical metric and US units specified in the table will yield flow coefficients in the units in which they are defined.

Table 2 — Typical values of values style modifier F_{d} , liquid pressure recovery factor F_{L} , and pressure differential ratio factor x_{T} at full rated travel ¹⁾

Valve type	Trim type	Flow direction ²⁾	F _	X _T	F _d
Globe,	3 V-port plug	Open or close	0.9	0.70	0.48
single port	4 V-port plug	Open or close	0.9	0.70	0.41
	6 V-port plug	Open or close	0.9	0.70	0.30
	Contoured plug (linear and	Open	0.9	0.72	0.46
	equal percentage)	Close	0.8	0.55	1.00
	60 equal diameter hole drilled cage	Outward ³⁾ or inward ³⁾	0.9	0.68	0.13
	120 equal diameter hole drilled cage	Outward ³⁾ or inward ³⁾	0.9	0.68	0.09
	Characterized cage, 4-port	Outward ³⁾	0.9	0.75	0.41
		Inward ³⁾	0.85	0.70	0.41
Globe,	Ported plug	Inlet between seats	0.9	0.75	0.28
	Contoured plug	Either direction	0.85	0.70	0.32
Globe, angle	Contoured plug (linear and	Open	0.9	0.72	0.46
	equal percentage)	Close	0.8	0.65	1.00
	Characterized cage, 4-port	Outward ³⁾	0.9	0.65	0.41
			0.85	0.60	0.41
	Venturi	Close	0.5	0.20	1.00
Globe, small flow trim	V-notch	Open	0.98	0.84	0.70
	Flat seat (short travel)	Close	0.85	0.70	0.30
	Tapered needle	Open	0.95	0.84	$N_{19} \frac{(CF_{\rm L})^{0.5}}{D_{\rm 0}}$
Rotary	Eccentric spherical plug	Open	0.85	0.60	0.42
	0	Close	0.68	0.40	0.42
	Eccentric conical plug	Open Close	0.77	0.54	0.44
		Close	0.79	0.55	0.44
Butterfly (centered shaft)	Swing-through (70°)	Either	0.62	0.35	0.57
(centered shart)	Swing-through (60°)	Either	0.70	0.42	0.50
	Fluted vane (70°)	Either	0.67	0.38	0.30
High Performance Butterfly (eccentric shaft)	Offset seat (70°)	Either	0.67	0.35	0.57
Ball	Full bore (70°)	Either	0.74	0.42	0.99
	Segmented ball	Either	0.60	0.30	0.98
 These values a Flow tends to c 	are typical only; actual values sha	Il be stated by the valve the closure device (plug	manufactur	er. c) away from (or towards the seat.

3) Outward means flow from center of cage to outside, and inward means flow from outside of cage to center.



NOTE 1 Pipe diameter *D* is the same size at both ends of the valve (see Equation 25).

NOTE 2 Refer to Annex F for example of the use of these curves.

Cog

Figure 2a — Piping geometry factor $F_{\rm P}$ for $K_{\rm v} / d^2$



NOTE 2 Refer to Annex F for example of the use of these curves.

Figure 2b — Piping geometry factor F_P for C_v / d^2



Figure 3a — Reynolds number factor F_{R} for full-size trim valves (reference Annex G)





Figure 4b — Butterfly valves and contoured plug, low flow valves (see legend)









Legend

- 1 Double seated globe valve, V-port plug
- 2 Ported cage guided globe valve (flow-to-open and flow-to-close)
- 3 Double seated globe valve, contoured plug
- 4 Offset seat butterfly valve
- 5 Swing-through butterfly valve
- 6 Contoured plug, low flow valve
- 7 Single port, equal percentage, contoured globe valve, flow-to-open

- 8 Single port, equal percentage, contoured globe valve, flow-to-close
- 9 Eccentric spherical plug valve, flow-to-open
- 10 Eccentric spherical plug valve, flow-to-close
- 11 Segmented ball valve
- 12 Eccentric conical plug valve, flow-to-open
- 13 Eccentric conical plug valve, flow-to-close

NOTE These values are typical only; actual values shall be stated by the manufacturer.



This page intentionally left blank.

Annex A(informative) — Derivation of valve style modifier F_{d}

All variables in this annex have been defined in this part except for the following:

- A_o area of vena contracta of a single flow passage, millimeters squared;
- $d_{\rm H}$ hydraulic diameter of a single flow passage, millimeters;
- *d*_i inside diameter of annular flow passage (see Figure A.1), millimeters;
- d_{o} equivalent circular diameter of the total flow area, millimeters;
- D_o diameter of seat orifice (see Figures A.1 and A.2), millimeters;
- $I_{\rm w}$ wetted perimeter of a single flow passage, millimeters;
- N_{o} number of independent and identical flow passages of a trim, dimensionless;
- α angular rotation of closure member (see Figure A.2), degrees;
- β maximum angular rotation of closure member (see Figure A^2), degrees;
- $\zeta_{\scriptscriptstyle B1}$ ~ velocity of approach factor, dimensionless; and
- μ discharge coefficient, dimensionless.

The valve style modifier F_{d} , defined as the ratio d_{H}/d_{o} at rated travel and where $C_{i}/d^{2} > 0.016 N_{18}$, may be derived from flow tests using the following equation:

Eq. A.1

$$F_{d} = \frac{N_{26} v F_{L}^{2} F_{R}^{2} (C/d^{2})^{2} \sqrt{CF_{L}}}{Q \left(\frac{F_{L}^{2} C^{2}}{N_{2} D^{4}} + 1\right)^{1/4}}$$

For valves having $C_{\rm i}/d^2 \le 0.016 N_{\rm 18}$, $F_{\rm d}$ is calculated as follows:

Eq. A.2
$$F_{d} = \frac{N_{31} v F_{L}^{2} F_{R}^{2} \sqrt{CF_{L}}}{Q \left[1 + N_{32} \left(\frac{C}{d^{2}}\right)^{2/3}\right]}$$

NOTE Values for N_{26} and N_{32} are listed in Table A.1.

The test for determining F_{d} is covered in IEC 60534-2-3.

Alternatively, F_{d} can be calculated by the following equation:

Eq. A.3
$$F_{\rm d} = \frac{d_{\rm H}}{d_{\rm o}}$$

The hydraulic diameter $d_{\rm H}$ of a single flow passage is determined as follows:

Eq. A.4
$$d_{\rm H} = \frac{4 A_{\rm o}}{I_{\rm w}}$$

The equivalent circular diameter d_{0} of the total flow area is given by the following equation:

Eq. A.5
$$d_{\rm o} = \sqrt{\frac{4N_{\rm o}A_{\rm o}}{\pi}}$$

 $F_{\rm d}$ may be estimated with sufficient accuracy from dimensions given in manufacturers' drawings.

The valve style modifier for a single-seated, parabolic valve plug (flow tending to open) (see Figure A.1) may be calculated from Equation A.3.

From Darcey's equation, the area A_0 is calculated from the following equation:

Eq. A.6
$$A_{\rm o} = \frac{N_{23}CF_{\rm L}}{N_{\rm o}}$$

NOTE Values for N_{23} are listed in Table A.1.

Therefore, since
$$N_0 = 1$$
,

Eq. A.7

The sequation, the area
$$A_o$$
 is calculated from the following end of $A_o = \frac{N_{23}CF_L}{N_o}$
for N_{23} are listed in Table A.1.
nce $N_o = 1$,
 $d_o = \sqrt{\frac{4A_o}{\pi}}$
 $= \sqrt{\frac{4N_{23}CF_L}{\pi}}$

 $d_{\rm H} = \frac{4A_{\rm o}}{I_{\rm w}}$

Eq. A.8

$$=\frac{4N_{23}CF_{L}}{\pi(D_{o}+d_{i})}$$
From above,

Eq. A.3
$$F_{d} =$$

$$=\frac{\left[\frac{4N_{23}CF_{L}}{\pi(D_{o}+d_{i})}\right]}{\sqrt{\frac{4N_{23}CF_{L}}{\pi}}}$$

 $\frac{d_{\rm H}}{d_{\rm o}}$

 $=\frac{1.13\sqrt{N_{23}CF_{L}}}{D_{o}+d_{i}}$ Eq. A.9

where d_i varies with the flow coefficient. The diameter d_i is assumed to be equal to zero when ,teccionamiento $N_{23}CF_{L} = D_{0}^{2}$. At low *C* values, $d_{l} \approx D_{0}$; therefore,

Eq A.10 $d_i = D_o - \frac{N_{23}CF_L}{D_o}$

Eq. A.11
$$F_{d} = \frac{1.13 \sqrt{N_{23} C F_{L}}}{2 D_{o} - \frac{N_{23} C F_{L}}{D}}$$

The maximum F_{d} is 1.0.

For swing-through butterfly valves, see Figure A.2.

The effective orifice diameter is assumed to be the hydraulic diameter of one of the two jets emanating from the flow areas between the disk and valve body bore; hence $N_0 = 2$.

The flow coefficient C at choked or sonic flow conditions is given as

Eq. A.12
$$N_{23}CF_{L} = \frac{0.125\pi D_{0}^{2}(\mu_{1} + \mu_{2})\left(\frac{1 - \sin\alpha}{\sin\beta}\right)}{\zeta_{B1}}$$

Assuming the velocity of approach factor ζ_{B1} = 1, making μ_1 = 0.7 and μ_2 = 0.7, and substituting equation A.6 into Equation A.12 yields Equation A.13.

Eq. A.13
$$A_{o} = \frac{0.55 D_{o}^{2} \left(\frac{1 - \sin \alpha}{\sin \beta}\right)}{N_{o}}$$

and since $\beta = 90^{\circ}$ for swing-through butterfly valves,

Eq. A.14
$$A_{o} = \frac{0.55 D_{o}^{2} (1 - \sin \alpha)}{N_{o}}$$

However, since there are two equal flow areas in parallel,

Eq. A.15
$$A_{o} = 0.275 D_{o}^{2} (1 - \sin \alpha)$$

and

$$d_{\rm o} = \sqrt{\frac{4A_{\rm o}N_{\rm o}}{\pi}}$$

 $= 0.837 D_{o} \sqrt{1 - \sin \alpha}$ Eq. A.16

$$d_{\rm H} = \frac{4A_{\rm o}}{0.59\pi D_{\rm o}}$$

Eq. A.3
$$F_{\rm d} = \frac{d_{\rm H}}{d_{\rm o}}$$

$$F_{d} =$$

ii		-				
Jahle	Δ1		Nume	rical	consta	int N
I GOIG	^		N ame	noui	0011310	

	d	$_{\rm H} = \frac{4A_{\rm o}}{0.59\pi D_{\rm o}}$			×O	
Eq.	q. A.17 = $0.59D_{o}(1 - \sin \alpha)$					
NO	NOTE 0.59 π D _o is taken as the wetted perimeter I _w of each semi-circle allowing for jet contraction and hub.					
Eq.	Eq. A.3 $F_{\rm d} = \frac{d_{\rm H}}{d_{\rm o}}$					
whi	which results in					
Eq.	Eq. A.18 $F_{\rm d} = 0.7\sqrt{1-\sin\alpha}$					
	Table A.1 — Numerical constant N					
		Flow coefficient C		Formulae unit		
	Constant	K _v	C _v	Q	d	ν
	N ₂₃	1.96 × 10 ¹	$1.70 imes 10^{1}$ $2.63 imes 10^{-2}$		mm in	
	N ₂₆	1.28×10^{7}	$9.00 imes 10^{6}$ $9.52 imes 10^{-5}$	m ³ C _v /h gpm	mm in	m²/s cS
	N ₃₁	2.1 × 10 ⁴	$1.9 imes 10^4$ $8.37 imes 10^{-2}$	m ³ /h gpm	mm in	m²/s cS
	N ₃₂	1.4 × 10 ²	1.27 × 10 ² 1.70		mm in	
I	NOTE Use of the numerical constant provided in this table together with the practical metric units specified in the table will yield flow coefficients in the units in which they are defined.					

- 39 - ANSI/ISA-75.01.01-2002 (IEC 60534-2-1 Mod)



Figure A.1 — Single seated, parabolic plug (flow tending to open)



Figure A.2 — Swing-through butterfly valve

This page intentionally left blank.



Annex B (informative) — Control valve sizing flow charts











Gas or vapor	Symbol	М	γ	F γ	P _c ²⁾	T _c ³⁾
Acetylene	C ₂ H ₂	26.04	1.30	0.929	6,140	309
Air	-	28.97	1.40	1.000	3,771	133
Ammonia	NH ₃	17.03	1.32	0.943	11,400	406
Argon	А	39.948	1.67	1.191	4,870	151
Benzene	C ₆ H ₆	78.11	1.12	0.800	4,924	562
Isobutane	C ₄ H ₉	58.12	1.10	0.784	3,638	408
n-Butane	C ₄ H ₁₀	58.12	1.11	0.793	3,800	425
Isobutylene	C ₄ H ₈	56.11	1.11	0.790	4,000	418
Carbon dioxide	CO ₂	44.01	1.30	0.929	7,387	304
Carbon monoxide	CO	28.01	1.40	1.000	3,496	133
Chlorine	Cl ₂	70.906	1.31	0.934	7,980	417
Ethane	C_2H_6	30.07	1.22	0.871	4,884	305
Ethylene	C_2H_4	28.05	1.22	0.87	5,040	283
Fluorine	F ₂	18.998	1.36	0.970	5,215	144
Freon 11 (trichloromonofluormethane)	CCI ₃ F	137.37	1.14	0.811	4,409	471
Freon 12 (dichlorodifluoromethane)	CCI_2F_2	120.91	1.13	0.807	4,114	385
Freon 13 (chlorotrifluoromethane)	CCIF	104.46	1 14	0.814	3,869	302
Freon 22 (chlorodifluoromethane)	CHCIF ₂	80.47	118	0.846	4,977	369
Helium	He	4.003	1.66	1.186	229	5.25
n-Heptane	C ₇ H ₁₆	100.20	1.05	0.750	2,736	540
Hydrogen	H ₂	2.016	1.41	1.007	1,297	33.25
Hydrogen chloride	HCI	36.46	1.41	1.007	8,319	325
Hydrogen fluoride	HF	20.01	0.97	0.691	6,485	461
Methane	CH₄	16.04	1.32	0.943	4,600	191
Methyl chloride	CH ₃ CI	50.49	1.24	0.889	6,677	417
Natural gas ⁴⁾	-	17.74	1.27	0.907	4,634	203
Neon	Ne	20.179	1.64	1.171	2,726	44.45
Nitric oxide	NO	63.01	1.40	1.000	6,485	180
Nitrogen	N ₂	28.013	1.40	1.000	3,394	126
Octane	C ₈ H ₁₈	114.23	1.66	1.186	2,513	569
Oxygen	0 ₂	32.000	1.40	1.000	5,040	155
Pentane	C ₅ H ₁₂	72.15	1.06	0.757	3,374	470
Propane	C ₃ H ₈	44.10	1.15	0.821	4,256	370
Propylene	C ₃ H ₆	42.08	1.14	0.814	4,600	365
Saturated steam	-	18.016	1.25 –	0.893 –	22,119	647
			1.32 ⁴⁾	0.943 ⁴⁾		
Sulphur dioxide	SO ₂	64.06	1.26	0.900	7,822	430
Superheated steam	-	18.016	1.315	0.939	22,119	647

Annex C (informative) — Physical constants ¹⁾

1) Constants are for fluids (except for steam) at ambient temperature and atmospheric pressure.

2) Pressure units are kPa (absolute).

3) Temperature units are in K.

4) Representative values; exact characteristics require knowledge of exact constituents.

This page intentionally left blank.

Annex D (informative) — Alternate non-turbulent flow calculation method

The following explicit calculation method may be used for liquids to compute the Reynolds Number Factor, $F_{\rm R}$, for valves where $C_{\rm v}/d^2$ is less than 30 when *d* is in inches; Q = U.S. gpm; ΔP is in psi.

D.1 Calculate a pseudo-Re_{vi}

Eq. D.1
$$Re_{vi} = N_4 \frac{Q}{v\sqrt{0.9C_{vT}}} \left[1 + \frac{0.8C_{vT}^2}{N_2 d^4}\right]^{1/4}$$

where

Eq. D.2
$$C_{\rm vT} = Q_{\rm v} \frac{G_{\rm f}}{\Delta P}$$

NOTE This calculation assumes the valve is a globe-type valve with an *F*_L of 0.9. rcie Ita perfecci

Eq. D.3
$$C_{vLi} = \frac{C_{vT}}{0.019Re_{vi}^{2/3}}$$

If $C_{\rm vli}/d^2 < 0.1$, then go to step D.4.

D.3 Calculate exponent, n:

NOTE Choose the rated $F_{\rm L}$ and $F_{\rm d}$ values for a selected valve type based on the preliminary laminar flow coefficient $C_{\rm vLi}$ from Equation D.3.

Eq. D.4

Eq. D.4
$$n_{1} = \left[\frac{29.9d^{2}}{C_{vLi}\left(\frac{0.9}{F_{L}}\right)^{0.7}}\right]^{2}$$
Eq. D.5
$$n_{2} = 1 + 1.7 \left[\frac{C_{vLi}}{d^{2}}\left(\frac{0.9}{F_{L}}\right)^{0.7}\right]^{2/3}$$

Eq. D.6
$$n = \begin{cases} n_1 & \text{if } n_1 \le 9 \\ n_2 & \text{if } n_1 > 9 \end{cases}$$

NOTE Neither *n* nor *n*₂ should be less than 1.0.

D.4 Compute laminar flow coefficient

If $0.1 < C_{vl_i}/d^2 < 30$ then

Eq. D.7

$$C_{\nu L} = \frac{0.192 \left(\frac{G_{\rm f} \nu Q}{\Delta P F_{\rm d} n}\right)^{2/3} F_{\rm L}^{1.667}}{\left[1 + \frac{C_{\nu Li}^2 F_{\rm L}^2}{N_2 d^4}\right]^{-1/6}}$$

If $C_{vli}/d^2 < 0.1$, then

Eq. D.8
$$C_{vL} = 0.194 \left(\frac{G_{f} vQ}{\Delta PF_{d}} \right)^{2/3} F_{L}^{1.667}$$

For needle-type trims, where

$$F_{\rm d} = 0.09 \frac{\sqrt{C_{\rm v} F_{\rm L}}}{D_{\rm o}}$$

then,

Eq. D.9
$$C_{\rm vL} = 0.973 \left[QG_{\rm f} \left(\frac{D_{\rm o}}{\Delta P} \right) \right]^{0.5}$$

where $\textit{D}_{_{\!\rm o}}$ is the orifice diameter in inches.

Perfeccionamiento D.5 Compute transitional flow coefficient

Eq. D.10
$$C_{vLt} = \frac{C_{vT}}{1 + \left(0.33 \frac{F_{L}^{0.5}}{n^{0.25}}\right) \log \left(1.73 F_{d} \frac{Q}{v C_{vL}^{0.5} F_{L}^{0.5}}\right)}$$

NOTE The value of n in the above equation should be determined from the Equations D.4 and D.5 but using C_{vL} as calculated from Equations D.7 or D.8 instead of C_{vLi} . For $C_{vLi}/d^2 < 0.1$ use n = 1

For $C_{vLi}/d^2 < 0.1$ and needle-type trims:

Eq. D.11
$$C_{vLt} = \frac{QG_{f}^{0.5}}{\Delta P^{0.5} \left[1 + 0.33 \log \left(\frac{0.156Q}{D_{o}v} \right) \right]}$$

D.6 Determine sizing flow coefficient

The largest of the turbulent flow coefficient, C_{VT} , transitional flow coefficient, C_{VLT} , or laminar flow coefficient, $C_{\rm vL}$, should be used for selecting the correct valve size.

D.7 Calculating the flow coefficient for gases

NOTE $q = \text{scfh}, \mu = \text{absolute viscosity of gas at inlet temperature in centipoise}, G_g = \text{specific gravity of gas.}$ Determine C_{vT} from Equation D.7 to D.9, or D.12 to D.15.

If $C_{vT}/d^2 < 0.1$, then:

Assuming Laminar Flow

Eq. D.12
$$C_{vL} = \frac{C_{vT} \sqrt{\mu C_{vT}}^{0.5}}{0.0423 \sqrt{qF_{d}G_{g}}}$$

For needle-type trims, where

$$F_{\rm d} = 0.09 \frac{\sqrt{C_v F_{\rm L}}}{D_{\rm o}}$$

then,

Eq. D.13
$$C_{vL} = \frac{C_{vT} \sqrt{\mu D_o}}{0.0127 \sqrt{qG_g}}$$

Assuming Transitional Flow

Eq. D.14
$$C_{vLt} = C_{vT} \left[\frac{\mu C_{vT}^{0.5}}{2.65 \times 10^{-4} F_{d} q G} \right]$$

For needle-type trims,

Eq. D.15
$$C_{vLT} = C_{vT} \left[\frac{100^{\circ}}{2.38 \times 10^{-5} qG_{g}} \right]^{0.18}$$

For sizing purposes, select the larger of the turbulent (C_{vT}) , the laminar (C_{vL}) , or the transitional flow Coefficient (C_{vL}) .

Example:

A 1/2" valve is required to pass 16.2 scfh gas at $G_g = 1.34$; $\mu = 0.0215$ cP; $P_1 = 190$ psia, and $P_2 = 170$ psia. C_{vT} calculated from the above is 0.005. The manufacturer stated orifice diameter D_o is 0.197 inches and a tapered, needle-type trim is used.

J^{0.18} Refeccionamiento

Here $C_v/d^2 = 0.005/0.5^2 \le 0.1$, so we can use Equations D.12 and D.15, respectively.

Assuming Laminar Flow

$$C_{\rm vL} = \frac{0.005\sqrt{0.0215 \times 0.197}}{0.0127\sqrt{16.3 \times 13.4}} = 0.0055$$

Assuming Transitional Flow

$$C_{\rm vLT} = 0.005 \left[\frac{0.0215 \, \text{x} \, 0.197}{2.38 \, \text{x} \, 10^{-5} \, \text{x} \, 16.3 \, \text{x} \, 1.34} \right]^{0.18} = 0.0073$$

Since $C_{\rm vLt}$ is larger, the selected trim size has to be 0.0073 or larger.

Reference Hans D. Baumann, "Control-Valve Sizing Improved," INTECH, June 1999, pp. 54-57.

copia para perfeccionamiento

Annex E (informative) — Units conversions

Pressure

bar =
$$0.0689476 \left(\frac{lbf}{in^2} \right)$$

 $kg/cm^2 = 0.070307 \left(\frac{lbf}{in^2} \right)$
 $kPa = 6.89476 \left(\frac{lbf}{in^2} \right)$
 $lbf/in^2 = 14.5038 (bar)$
 $lbf/in^2 = 14.2233 \left(\frac{kg}{cm^2} \right)$
 $lbf/in^2 = 0.145038 (kPa)$
Liquid Flow Rate
 $m^3/nr = 0.2271246 \left(\frac{gal}{min} \right)$
 $m^3/nr = 0.0066245 \left(\frac{bbl}{day} \right)$
 $kg/nr = 0.4535924 \left(\frac{lbm}{hr} \right)$
Gas Flow Rate
 $m^3/hr|_{stto} = 0.0283168 \left(\frac{tt^3}{hr}|_{stto} \right)$
 $m^3/hr|_{actual} = 0.011725 \left(\frac{m^3/hr}{stto} \right) \frac{7Z}{P}$
where, *T* is in K
P is in kPa

 $\frac{\text{kg}}{\text{hr}} = 0.4535924 \left(\frac{\text{lbm}}{\text{hr}} \right)$

Gas Molecular Weight

M = 28.97 (specific gravity)

Liquid Density

$$\rho = \frac{\text{kg}}{\text{m}^3} = 999.9687 \text{ (Specific Gravity)}$$

Gas Density

$$\rho = \frac{\text{kg}}{\text{m}^3} = \frac{MP}{8.314TZ}$$

where, T is in K

P is in kPa

$$P \text{ is in kPa}$$

$$p = \frac{\text{kg}}{\text{m}^3} = \frac{MP}{1.205843(T + 459.67)Z}$$
where, *T* is in °F
$$P \text{ is in lbf/in}^2$$

$$p = \frac{\text{kg}}{\text{m}^3} = \frac{MP}{815.325(T + 273.15)Z}$$
where, *T* is in °C
$$P \text{ is in kg/cm}^2$$

$$p = \frac{\text{kg}}{\text{m}^3} = \frac{MP}{831.4(T + 273.15)Z}$$
where, *T* is in °C

where, T is in °F

P is in lbf/in²

$$\rho = \frac{kg}{m^3} = \frac{MP}{815.325(T + 273.15)Z}$$

where, *T* is in °C

P is in kg/cm²

$$\rho = \frac{kg}{m^3} = \frac{MP}{831.4(T + 273.15)Z}$$

where, T is in °C

P is in bar

Dynamic Viscosity

$$\mu = \frac{\text{lbf} \cdot \text{s}}{\text{ft}^2} = \frac{\text{slugs}}{\text{ft} \cdot \text{s}}$$
$$\mu = cP = \frac{\text{kg}}{\text{m} \cdot \text{s}}$$
$$cP = 92903 \left(\frac{\text{lbf} \cdot \text{s}}{\text{ft}^2}\right)$$

Kinematic Viscosity

$$v = cS = \frac{1000\mu}{\rho}$$

where, v is in °C

ρ is in kg/m³

$$v = cS = 1,000,000 \frac{m^2}{s}$$

 $v = cS = 92,903 \frac{ft^2}{s}$

copia para perfeccionamiento

This page intentionally left blank.

Annex F (informative) — Examples of sizing calculations

Example 1: Incompressible flow – non-choked turbulent flow without attached fittings

Process data:	
Fluid:	water
Inlet temperature:	T ₁ = 363 K
Density: ρ_1	= 965.4 kg/m ³
Vapor pressure:	<i>P_v</i> = 70.1 kPa
Thermodynamic critical pressure:	<i>P</i> _c = 22,120 kPa
Kinematic viscosity:	$v = 3.26 \times 10^{-7} \text{ m}^2/\text{s}$
Inlet absolute pressure:	P ₁ = 680 kPa
Outlet absolute pressure:	P ₂ = 220 kPa
Flow rate:	$Q = 360 \text{ m}^3/\text{h}$
Pipe size:	$D_1 = D_2 = 150 \text{ mm}$
Valve data:	200
Valve style:	glabe
Trim:	parabolic plug
Flow direction:	flow-to-open
Valve size:	<i>d</i> = 150 mm
Liquid pressure recovery factor:	$F_{\rm L}$ = 0.90 (from Table 2)
Valve style modifier:	$F_{\rm d}$ = 0.46 (from Table 2)
Calculations:	

Eq. 31
$$F_{\rm F} = 0.96 - 0.28 \sqrt{\frac{P_{\rm v}}{P_{\rm c}}} = 0.944$$

where

 $P_{\rm V} = 70.1$ kPa; and

 $P_{\rm c} = 22,120$ kPa.

Next, determine the type of flow:

$$F_{\rm L}^{2}(P_{\rm 1}-F_{\rm F}\times P_{\rm v})=497.2$$
 kPa

which is more than the differential pressure ($\Delta P = 460$ kPa); therefore, the flow is non-choked, and the flow coefficient C is calculated using Equation 1.

Eq. 1
$$C = \frac{Q}{N_1} \sqrt{\frac{\rho_1 / \rho_o}{\Delta P}} = 165 \text{ m}^3/\text{h for } K_v$$

where

$$Q = 360 \text{ m}^3 / \text{h};$$

 $N_1 = 1 \times 10^{-1}$ from Table 1;

$$\rho_1 / \rho_0 = 0.965$$
; and

 $\Delta P = 460 \text{ kPa}.$

Next, calculate Re_v.

Eq. 28

where

$$N_2 = 1.60 \times 10^{-3}$$
 from Table 1;

$$N_1 = 1 \times 10^{-1}$$
 from Table 1;
 $\rho_1/\rho_0 = 0.965$; and
 $\Delta P = 460 \text{ kPa.}$
Next, calculate Re_v .
Eq. 28 $Re_v = \frac{N_4 F_d Q}{v \sqrt{C_1 F_L}} \left[\frac{F_L^2 C_1^2}{N_2 D^4} + 1 \right]^{1/4} = 2.967 \times 10^6$
where
 $N_2 = 1.60 \times 10^{-3}$ from Table 1;
 $N_4 = 7.07 \times 10^{-2}$ from Table 1;
 $F_d = 0.46$;
 $Q = 360 \text{ m}^3/\text{h}$;

 $F_{\rm d} = 0.46;$

 $Q = 360 \text{ m}^3/\text{h};$

 $v = 3.26 \times 10^{-7} \text{ m}^2/\text{s}$:

$$C_{\rm i} = {\rm C} = K_{\rm v} = 165 {\rm m}^3 {\rm / h};$$

 $F_1 = 0.90$; and

D = 150 mm.

Since the valve Reynolds number is greater than 10,000, the flow is turbulent, and the flow coefficient C as calculated above is correct.

Example 2: Incompressible flow – choked flow without attached fittings

Process data:

Fluid:	water
Inlet temperature:	T ₁ = 363 K
Density: $\rho_1 = 96$	5.4 kg/m ³
Vapor pressure:	<i>P</i> _v = 70.1 kPa
Thermodynamic critical pressure:	<i>P</i> _c = 22,120 kPa
Kinematic viscosity:	$v = 3.26 \times 10^{-7} \text{ m}^2/\text{s}$
Inlet absolute pressure:	<i>P</i> ₁ = 680 kPa
Outlet absolute pressure:	<i>P</i> ₂ = 220 kPa
Flow rate:	Q = 360 m ³ /h
Pipe size:	$D_1 = D_2 = 100 \text{ mm}$
Valve data:	alli
Valve style:	ball valve
Trim:	segmented ball
Flow direction:	flow-to-open
Valve size:	<i>d</i> = 100 mm
Liquid pressure recovery factor:	$F_{L} = 0.60$ (from Table 2)
Valve style modifier:	$F_{\rm d}$ = 0.98 (from Table 2)
Calculations:	
Eq. 31 $F_{\rm F} = 0.96 - 0.28 \sqrt{\frac{P_{\rm v}}{P_{\rm c}}} =$	= 0.944

where

$$P_{v} = 70.1 \text{ kPa}; \text{ and}$$

 $P_{\rm c} = 22,120$ kPa.

Next, determine the type of flow.

$$F_{\rm L}^{2}(P_{\rm 1}-F_{\rm F}\times P_{\rm v})=221$$
 kPa

which is less than the differential pressure (ΔP = 460 kPa); therefore, the flow is choked and the flow coefficient C is calculated using Equation 3.

Eq. 3
$$C = \frac{Q}{N_1 F_L} \sqrt{\frac{\rho_1 / \rho_o}{P_1 - F_F P_v}} = 238 \text{ m}^3/\text{ h for } K_v$$

where

where

$$Q = 360 \text{ m}^3/\text{h};$$

 $N_1 = 1 \times 10^{-1} \text{ from Table 1};$
 $F_L = 0.60;$
 $\rho_1/\rho_0 = 0.965;$
 $P_1 = 680 \text{ kPa},$
 $F_F = 0.944; \text{ and}$
 $P_v = 70.1 \text{ kPa}.$
Next, calculate $Re_v.$
Eq. 28 $Re_v = \frac{N_4 F_0 Q}{v\sqrt{C_1 F_L}} \left[\frac{F_L^2 C_1^2}{N_2 D^4} + 1\right]^{1/4} = 6.598 \times 10^6$

where

$$N_2 = 1.60 \times 10^{-3}$$
 from Table 1;
 $N_4 = 7.07 \times 10^{-3}$ from Table 1;
 $F_d = 0.98$;

 $Q = 360 \text{ m}^3/\text{ h};$

 $v = 3.26 \times 10^{-7} \text{ m}^2/\text{ s};$

$$C_{\rm i} = C = K_{\rm v} = 238 \text{ m}^3/\text{ h};$$

 $F_{\rm L} = 0.60;$ and

D = 100 mm.

Process data:

Since the valve Reynolds number is greater than 10,000, the flow is turbulent and no more correction is necessary.

Example 3: Compressible flow – non-choked flow with attached fittings

Fluid: carbon dioxide $T_1 = 433 \text{ K}$ Inlet temperature: Molecular mass: M = 44.01 kg/kmolonamiente $v = 1.743 \times 10^{-5} \text{ m}^2/\text{s}$ Kinematic viscosity: Specific heat ratio: $\gamma = 1.30$ Z = 0.988Compressibility factor: $P_1 = 680 \text{ kPa}$ Inlet absolute pressure: $P_2 = 310 \text{ kPa}$ Outlet absolute pressure: Q = 3,800 standard m³/h at 101.325 kPa and 0°C Flow rate: = 80 mm Inlet pipe size: $D_2 = 100 \text{ mm}$ Outlet pipe size: short length, concentric Reducers: Valve data: Valve style: rotary Trim: eccentric rotary plug Flow direction: flow-to-open Valve size: d = 50 mmPressure differential ratio factor: $x_{\rm T}$ = 0.60 (from Table 2) $F_{\rm I} = 0.85$ (from Table 2) Liquid pressure recovery factor: $F_{d} = 0.42$ (from Table 2) Valve style modifier: Calculations:

Eq. 34
$$F_{\gamma} = \frac{\gamma}{1.40} = 0.929$$

where

$$\gamma = 1.30.$$

and with this

$$x = \frac{\Delta P}{P_1} = 0.544$$

which is less than $F_{\gamma}x_{T} = 0.557$; therefore, the flow is non-choked and the flow coefficient is calculated from Equation 11. Next, Y is calculated from Equation 32;

Eq. 32

$$Y = 1 - \frac{x}{3F_{\gamma}x_{\tau}} = 0.674$$
where
 $x = 0.544$;
 $F_{\gamma} = 0.929$; and
 $x_{\tau} = 0.60$
Eq. 11

$$C = \frac{Q}{N_{9}F_{p}P_{1}Y}\sqrt{\frac{MT_{1}Z}{x}} = 62.7 \text{ m}^{2}/\text{h for } K_{v}$$
where
 $Q = 3,800 \text{ m}^{3}/\text{h}$;
 $N_{9} = 2.46 \times 10^{1} \text{ for } t_{s} = 0^{\circ}\text{C} \text{ from Table 1}$;
assume $F_{p} = 1$;

where

$$x = 0.544;$$

$$F_{\gamma}$$
 = 0.929; and

 $x_{\rm T} = 0.60$

Eq. 11
$$C = \frac{Q}{N_9 F_p P_1}$$

where

$$Q = 3,800 \text{ m}^3/\text{h};$$

$$N_9 = 2.46 \times 10^1$$
 for $t_s = 0^{\circ}$ C from Table 1;

assume $F_{\rm P} = 1$;

 $P_1 = 680 \text{ kPa};$

$$Y = 0.674;$$

M = 44.01 kg/kmol;

 $T_1 = 433 \text{ K};$

Z = 0.988; and

x = 0.544

Now, calculate Re, using Equation 28.

Eq. 28
$$Re_v = \frac{N_4 F_d Q}{v\sqrt{C_i F_L}} \left[\frac{F_L^2 C_i^2}{N_2 D^4} + 1 \right]^{1/4} = 8.96 \times 10^5$$

where

 $N_2 = 1.60 \times 10^{-3}$ from Table 1; $N_4 = 7.07 \times 10^{-2}$ from Table 1; $F_{\rm d} = 0.42;$ $Q = 3,800 \text{ m}^3/\text{h};$ $v = 1.743 \times 10^{-5} \text{ m}^2/\text{s};$ $C_{i} = C = K_{v} = 62.7 \text{ m}^{3}/\text{h};$

 $F_1 = 0.85$; and

D = 80 mm.

ara perfeccionamiento Ver thr Since the valve Reynolds number is greater than 10,000, the flow is turbulent.

Now, calculate the effect of the inlet and outlet reducers on C.

Since both reducers are concentric, short length, the velocity head loss coefficients can be calculated as follows:

 $\zeta_1 = 0.5 \left[1 - \left(d / D_1 \right)^2 \right]^2 = 0.186$ Eq. 23

where

d = 50 mm;

 $D_1 = 80 \text{ mm}; \text{ and }$

Eq. 24 $\zeta_1 = 1.0 \left[1 - \left(\frac{d}{D_2} \right)^2 \right]^2 = 0.563$

where

d = 50 mm;

 $D_2 = 100 \text{ mm};$

and the Bernoulli coefficients are

 $\zeta_{B1} = 1 - (d/D_1)^2 = 0.847$ Eq. 22

where

d = 50 mm;

 $D_1 = 80$ mm; and

 $\zeta_{B2} = 1 - (d/D_2)^4 = 0.938$

$$D_2 = 100$$
 mm.

Eq. 21
$$\Sigma \zeta = \zeta_1 + \zeta_2 + \zeta_{B1} - \zeta_{B2} = 0.658$$

$$\zeta_1 = 0.186$$

$$\zeta_2 = 0.563$$

$$\zeta_{B1} = 0.847$$

$$\zeta_{B2} = 0.938$$

Now, the effect of the reducers is calculated by iteration, starting with $C_i = C$ and $F_{P(1)} = 1$.

Eq. 20
$$F_{p(2)} = \frac{1}{\sqrt{1 + \frac{\Sigma\zeta}{N_2} \left(\frac{C_1}{d^2}\right)^2}} = 0.891$$

where

 $\Sigma \zeta = 0.658;$

 $N_2 = 1.60 \times 10^{-3}$ from Table 1;

 $C_1 = 62.7 \text{ m}^3/\text{h}; \text{ and}$

d = 50 mm.

Since $F_{P(2)}/F_{P(1)} = 0.891/1 < 0.99$, one more iteration step shall be done.

$$C_2 = \frac{C}{F_{p(2)}} = \frac{62.7}{0.891} = 70.4 \text{ m}^3/\text{h}$$

Eq. 20

$$F_{p(3)} = \frac{1}{\sqrt{1 + \frac{\Sigma\zeta}{N_2} \left(\frac{C_2}{d^2}\right)^2}} =$$

where

$$\Sigma \zeta = 0.658;$$

$$N_2 = 1.60 \times 10^{-3}$$
 from Table 1;

 $C_2 = 70.4 \text{ m}^3/\text{h}; \text{ and}$

Now,
$$F_{P(3)}/F_{P(2)} = 0.868/0.891 > 0.99$$
 so $F_{P(3)}$ will be used as F_{P} for the final calculation

Eq. 20

$$F_{p(3)} = \frac{1}{\sqrt{1 + \frac{\Sigma\zeta}{N_2} \left(\frac{C_2}{d^2}\right)^2}} = 0.868$$
where
 $\Sigma\zeta = 0.658;$
 $N_2 = 1.60 \times 10^{-3}$ from Table 1;
 $C_2 = 70.4 \text{ m}^3/\text{h};$ and
 $d = 50 \text{ mm.}$
Now, $F_{P(3)}/F_{P(2)} = 0.868/0.891 > 0.99 \text{ so } F_{P(3)}$ will be used as F_p for the final calculation
Eq. 33
 $x_{TP} = \frac{\frac{X_T}{F_2^2}}{1 + \frac{X_T\zeta_1}{N_5} \left(\frac{C_2}{d^2}\right)^2} = 0.626$

where

 $x_{\rm T} = 0.60;$

$$F_{\rm P} = 0.868;$$

 $\zeta_1 = \zeta_1 + \zeta_{B1} = 1.033;$

 $N_{\rm 5} = 1.80 \times 10^{-3}$ from Table 1;

$$C_2 = 70.4 \text{ m}^3/\text{h};$$

d = 50 mm;

and with this $F_{\gamma} x_{\text{TP}} = 0.582$, which is greater than x = 0.544.

Finally, C results from Equation 11 as follows:

Eq. 11
$$C = \frac{Q}{N_9 F_p P_1 Y} \sqrt{\frac{MT_1 Z}{x}} = 72.2 \text{ m}^3/\text{h for } K_v$$

where

 $Q = 3,800 \text{ m}^3/\text{h};$

 $N_9 = 2.46 \times 10^1$ for $t_s = 0$ °C from Table 1;

 $F_{\rm P} = 0.868;$

 $P_1 = 680 \text{ kPa};$

$$Y = 0.674;$$

M = 44.01 kg/kmol;

 $T_1 = 433$ K;

Z = 0.988; and

x = 0.544

para perfeccionamiento all fr Example 4: Compressible flow - small flow trim sized for gas flow

Process data:

Fluid:	argon gas
Inlet temperature:	<i>T</i> ₁ = 320 K
Inlet absolute pressure:	$P_1 = 2.8$ bar (absolute)
Outlet absolute pressure:	$P_2 = 1.3$ bar (absolute)
Flow rate:	Q = 0.46 standard m ³ /h at 1,013.25 mbar and 47°C
Molecular mass:	<i>M</i> = 39.95
Kinematic viscosity:	ν = 1.338 \times 10 $^{-5}$ m $^2/\!s$ at 1 bar (absolute) and 15 $^\circ C$
Specific heat ratio:	γ = 1.67

 $F_{\gamma} = 1.19$ Specific heat ratio factor:

Valve data:

Trim: tapered needle plug

 $F_1 = 0.98$ Liquid pressure recovery factor:

Pressure differential ratio factor: $x_{\rm T} = 0.8$

Orifice diameter: $D_{o} = 5 \text{ mm}$

Valve size:

Internal diameter of piping: D = 15 mm

Calculation:

The first step is to check the Reynolds number Re,.

Eq. 28
$$\operatorname{Re}_{v} = \frac{N_{4}F_{d}Q}{v\sqrt{C_{i}F_{L}}} \left[\frac{F_{L}^{2}C_{i}^{2}}{N_{2}D^{4}} + 1\right]^{1/4}$$

onamiento This requires input of C_i , which has to be determined. Since $x < F_{\gamma}x_T$, the flow coefficient can be estimated by first using the nonchoked flow Equation 8 to calculate C, then multiplying C by 1.3 in accordance with the iteration procedure of 8.1.

d = 15 mm

Eq. 32

$$Y = 1 - \frac{x}{3 F_{\gamma} x_{T}} = 0.812$$

$$C = \frac{Q}{N_{9} P_{1} Y} \sqrt{\frac{M T_{1} Z}{2}} = 0.0138 \text{ for } C_{v}$$

where

Eq. 8

 $Q = 0.46 \text{ m}^3/\text{h};$

 $N_{\rm g} = 2.25 \times 10^3$ for $t_{\rm s} = 15^{\circ}$ C from Table 1;

 $P_1 = 2.8$ bar;

M = 39.95 kg/kmol;

 $T_1 = 320 \text{ K};$

Z = 1;

 $F_{\gamma} = 1.19;$

x = 0.536; and

Y = 0.812.

Eq. 26
$$C_i = 1.3 C = 0.0179$$
 for C_v

where

$$C = 0.0138$$
 for C_{v} .

Next, estimate F_{d} from the equation in Table 2.

$$F_{\rm d} = \frac{N_{19}\sqrt{CF_{\rm L}}}{D_{\rm o}} = 0.061$$

where

$$C = C_{\rm i} = 0.0179$$
 for $C_{\rm v}$;

$$F_1 = 0.98;$$

 $N_{19} = 2.3$ from Table 1; and

$$D_{\circ} = 5$$
 mm.

Calculate *Re*, as follows:

$$C = C_{i} = 0.0179 \text{ for } C_{v};$$

$$F_{L} = 0.98;$$

$$N_{19} = 2.3 \text{ from Table 1; and}$$

$$D_{o} = 5 \text{ mm.}$$
Calculate Re_{v} as follows:
Eq. 28
$$Re_{v} = \frac{N_{4}F_{d}Q}{v\sqrt{C_{i}F_{L}}} \left[\frac{F_{L}^{2}C_{i}^{2}}{N_{2}D^{4}} + 1\right]^{1/4} = 1202$$
where

$$N_{2} = 2.14 \times 10^{-3} \text{ from Table 1;}$$

$$N_{4} = 7.6 \times 10^{-2} \text{ from Table 1;}$$

$$F_{d} = 0.061;$$

$$F_{\rm d} = 0.061;$$

 $Q = 0.46 \text{ m}^3/\text{h};$

$$v = 1.338 \times 10^{-5} \text{ m}^2/\text{s};$$

 $F_{\rm L} = 0.98;$

 $C_{\rm i} = 0.0179$ for $C_{\rm v}$; and

D = 15 mm.

Determine if $C/d^2 < 0.016 N_{18}$.

 $C/d^{2} = 7.97 \times 10^{-5}$

 $0.016 N_{18} = 0.016$

 $C/d^2 < 0.016 N_{18}$

where

 $N_{18} = 1.00$ from Table 1;

C = 0.0179; and

d = 15 mm.

Since the Reynolds number is below 10,000, the flow is non-turbulent; hence flow coefficient Equation G.3b has to be used. Since $C/d^2 < 0.016 N_{18}$ and $Re_v > 10$, calculate F_R from both Equations G.3a and G.4 and use the lower value (reference Annex G).

Eq. G.3b
$$n_2 = 1 + N_{32} \left(\frac{C_i}{d^2}\right)^{2/3} = 1.235$$

where

 $N_{32} = 1.27 \text{ x } 10^2 \text{ from Table 1;}$

 $C_{\rm i} = 0.0179$ for $C_{\rm vi}$

 $Re_v = 1,202$; and

d = 15 mm.

Eq. G.3a
$$F_{\rm R} = 1 + \left(\frac{0.33F_{\rm V}^{1/2}}{R_2^{1/4}}\right) \log_{10}\left(\frac{Re_{\rm v}}{10,000}\right) = 0.715$$

where

 $F_{\rm L} = 0.98;$

 $n_2 = 1.235$; and

 $Re_v = 1,202.$

Eq. G.4
$$F_{\rm R} = \frac{0.026}{F_{\rm L}} \sqrt{n_2 R e_{\rm v}} = 1.022$$

NOTE F_{R} is limited to 1.

where

$$F_{\rm L} = 0.98;$$

 $n_2 = 1.235$; and

 $Re_v = 1,202.$

Use $F_{\rm R} = 0.715$, the lower of the two calculated values.

Eq. 19
$$C = \frac{Q}{N_{22}F_{\rm R}} \sqrt{\frac{MT_1}{\Delta P(P_1 + P_2)}} = 0.0184 \text{ for } C_{\rm v}$$

where

 $Q = 0.46 \text{ m}^3/\text{h};$

 $\frac{C}{F_{R}} < C_{i} \qquad \text{copia para perfection anti-entropy} > 0.0179$ $N_{22} = 1.59 \times 10^3$ for $t_s = 15^{\circ}$ C from Table 1;

 $F_{\rm R} = 0.715;$

M = 39.95 kg/kmol;

$$T_1 = 320 \text{ K};$$

 $\Delta P = 1.5$ bar;

$$P_{1} = 2.8$$
 bar; and

$$P_2 = 1.3$$
 bar.

Check:

 $\frac{0.0138}{0.715} = 0.0193 > 0.0179$

Since C/F_{R} is not less than C_{i} , repeat the iteration process by increasing C_{i} by 30%.

New $C_i = 1.3 C_i = 0.0233$

where

 $C_{i} = 0.0179;$

$$F_{\rm d} = \frac{N_{19}\sqrt{CF_{\rm L}}}{D_{\rm o}} = 0.070$$

where

$$C = C_{\rm i} = 0.0233$$
 for $C_{\rm v}$;

 $F_1 = 0.98;$

 $N_{19} = 2.3$ from Table 1; and

$$D_{\circ} = 5 \text{ mm}.$$

Calculate Rev.

Eq. 28
$$Re_v = \frac{N_4 \cdot F_d \cdot Q}{v \sqrt{C_i \cdot F_L}} \left[\frac{F_L^2 C_i^2}{N_2 D^4} + 1 \right]^{1/4} = 1,202$$

where

ia para perfeccionamiento same = nd f $N_2 = 2.14 \times 10^{-3}$ from Table 1; $N_4 = 7.6 \times 10^{-2}$ from Table 1; $F_{\rm d} = 0.070;$ $Q = 0.46 \text{ m}^3/\text{h};$ $v = 1.338 \times 10^{-5} \text{ m}^2/\text{s};$ $F_{\rm L} = 0.98;$ $C_{\rm i}$ = 0.0233; and *D* = 15 mm.

Since the value of Re_v remains the same as previously calculated, F_R remains at 0.715. Therefore, the calculated C will remain at 0.0184 and any trim with a rated C of 0.0184 or higher for C_v is appropriate. This page intentionally left blank.

Annex G (informative) — Equations for Reynolds number factor, F_{R}

For full size trim where $C_i/d^2 \ge 0.016 N_{18}$ and $Re_v \ge 10$, calculate F_R from the following equations:

Eq. G.1a
$$F_{\rm R} = 1 + \left(\frac{0.33 F_{\rm L}^{1/2}}{n_1^{1/4}}\right) \log_{10}\left(\frac{Re_{\rm v}}{10,000}\right)$$

for the transitional flow regime,

where

Eq. G.1b
$$n_1 = \frac{N_2}{\left(\frac{C_i}{d^2}\right)}$$

or

or
Eq. G.2
$$F_{\rm R} = \frac{0.026}{F_{\rm L}} \sqrt{n_{\rm I} R e_{\rm v}}$$
 (not to exceed $F_{\rm R} = 1$)

for the laminar flow regime.

NOTE 1 Use the lower value of $F_{\rm R}$ from Equations G.1a and G.2. If $Re_{\rm v}$ <10, use only Equation G.2.

NOTE 2 Equation G.2 is applicable to fully developed aminar flow (straight lines in Figure 3a). The relationships expressed in Equations G.1a and G.2 are based on test data with valves at rated travel and may not be fully accurate at lower valve travels.

NOTE 3 In Equations G.1b and G.2, C_i / c_i^2 must not exceed 0.04 when K_v is used or 0.047 when C_v is used.

For reduced trim values where C_i/d^2 at rated travel is less than 0.016 N_{18} and $Re_v \ge 10$, calculate F_R from the following equations:

Eq. G.3a
$$F_{\rm R} = 1 + \left(\frac{0.33 F_{\rm L}^{1/2}}{n_2^{1/4}}\right) \log_{10}\left(\frac{Re_{\rm v}}{10,000}\right)$$

for the transitional flow regime,

where

Eq. G.3b
$$n_2 = 1 + N_{32} \left(\frac{C_i}{d^2}\right)^{2/3}$$

or

Eq. G.4
$$F_{\rm R} = \frac{0.026}{F_{\rm L}} \sqrt{n_2 R e_{\rm v}}$$
 (not to exceed $F_{\rm R}$ =1)

for the laminar flow regime.

- NOTE 1 Select the lowest value from Equations G.3a and G.4. If Re_v<10, use only Equation G.4.
- NOTE 2 Equation G.4 is applicable to fully developed laminar flow (straight lines in Figure 3b).

copia para perfeccionamiento
Annex H (informative) — Bibliography

INTERNATIONAL ELECTROTECHNICAL COMMISSION (IEC)

- IEC 60534-1 Part 1: Control Valve Terminology and General Considerations, 1987
- IEC 60534-2-1 Part 2-1: Flow Capacity; Sizing Equations for Fluid Flow Under Installed Conditions, 1998

IEC 60534-2-3 Part 2-3: Flow Capacity - Test Procedures, 1997

Available from: ANSI 25 West 43rd Street Fourth Floor New York, NY 10036

ISA

ANSI/ISA-75.02-1996 Control Valve Capacity Test Procedures

ANSI/ISA-75.05.01-2000 Control Valve Terminology

Baumann, H.D., "Effect of Pipe Reducers on Control Valve Capacity," *Instruments and Control Systems*, December 1968.

Baumann, H.D., "The Introduction of a Critical Flow Factor for Valve Sizing," *ISA Transactions*, Vol. 2., 1963.

Buresh, J.F. and C. B. Schuder, "The Development of a Universal Gas Sizing Equation for Control Valves," *ISA Transactions*, Vol. 3, 1964.

Driskell, L.R., Control Valve Selection and Sizing, 1983.

George, J.A., Evolution and Status of Nonturbulent Flow Sizing for Control Valves, 2001.

ISA Handbook of Control Valves, 2nd ed., 1976.

McCutcheon, E.B., "A Reynolds Number for Control Valves," *Symposium on Flow, Its Measurement and Control in Science and Industry*, Vol. 1, Part 3, 1974.

Available from:

ISA 67 Alexander Drive PO Box 12277 Research Triangle Park, NC 27709 Tel: (919) 990-9200

MISCELLANEOUS

Allen, W.F., Jr., "Flow of a Flashing Mixture of Water and Steam Through Pipes and Valves," Journal of Basic Engineering, April 1951.

Bailey, J.F., "Metastable Flow of Saturated Water," Journal of Basic Engineering, November 1951

Baumann, H.D., "A Unifying Method for Sizing Throttling Valves Under Laminar or Transitional Flow Conditions," Journal of Fluids Engineering, Vol. 115, No. 1, March 1993, pp. 166-168.

Burnell, J.G., "Flow of Boiling Water through Nozzles, Orifices and Pipes," *Engineering*, December 12, 1947.

Singleton, E.W., Multistage Valve Sizing Made Easy," INTECH, August 1997, pp. 47-51.

Stiles, G.F., "Liquid Viscosity Effects on Control Valve Sizing," Technical Manual TM 17A, October 1967, Fisher Governor Company, Marshalltown, Iowa.

.nu cooia para perfeccionamiento cooia para perfecciona

This page intentionally left blank.

Developing and promulgating sound consensus standards, recommended practices, and technical reports is one of ISA's primary goals. To achieve this goal the Standards and Practices Department relies on the technical expertise and efforts of volunteer committee members, chairmen and reviewers.

ISA is an American National Standards Institute (ANSI) accredited organization. ISA administers United States Technical Advisory Groups (USTAGs) and provides secretariat support for International Electrotechnical Commission (IEC) and International Organization for Standardization (ISO) committees that develop process measurement and control standards. To obtain additional information on the Society's standards program, please write:

ISA Attn: Standards Department 67 Alexander Drive P.O. Box 12277 Research Triangle Park, NC 27709

ISBN: 1-55617-780-1